


Instruction Manual

4K CAPTURE / PIP&PMP 2CH Display
(Recording,Pre-recording,playback)




BOX CONTENTS



A




B




C




D



E



F



G

A. 7inch capture box
B. HDMI CABLE
G. Power 12v1.5a

C. USB CABLE TO PC
D. SOFTWARE CD

E. REMOTE CONTROL
F. USER'S MANUAL

Specifications:

HD1/HD2 Video input :resolutions up to 4096 x 2160P60hz/1080P144hz/1080P120hz

Record Resolution: 1920x1080/1024X768/1280X720/1280X1024

Recrod format: MP4(H.264)

Supports: UVC & UAC USB (Flash MAX 512G, hard disk (FAT32, NTFS, exFAT etc MAX 8T)
SD (FAT32, NTFS, MAX 512G)

Supports UVC & UAC

Supports video streaming software OBS / XSplit

Sampling rate: 48kHz PCM

Compatible with Windows 10 , Mac OS & Linux

Built-in audio control software (control Line in, MIC, Line Out)

Compatibility with 3rd party application software

Linux Ubuntu 14.04

OBS (Windows, Mac)

XSplit (Windows)

Wirecast (Windows, Mac)

Adobe Flash Media Live Encoder (Windows)

DirectShow (Windows)

DirectSound (Windows)

QuickTime Player (Mac)

VLC (Mac)

Safari (Mac)

Firefox (Mac)

Chrome (Mac)





Skype (Mac)

UXPlayer software:

Capture 1080p30hz

Streaming to Twitter,Facebook,Youtube

GIF






HD1 MAX:4K60HZ
1080P144HZ
1080P120HZ
HD2 MAX:4K30HZ


Light info:Blue 1080P60hz
Below Green 1080P60hz(720P etc)



In PIP,PMP mode:
the screen is switched to each other

Three modes
Picture in picture 
left and right 
up and down 

LED






Snapshot photo (*.jpg files)
Recording video (*.MP4 files)
Stop recording video

Menu settings: Playback,Prerecorded,system time
Resolution, bit rate setting,etc

Led Light : USB (U disk, hard disk)
SD CARD and PC mode

Up, down, left and right buttons:
Can be moving for the for the PIP mode






HD1 Max:4K60hz INPUT

Support:1080p144hz,1080p120hz,1080p60hz etc

HD2 Max 4K30hz INPUT

Support:4k30hz,1080p60 etc







Battery:SONY NP-F550/F750/F970 7.4V





Battery:CR2032 (not included)



SYSTEM SETTING

System Setting    

language	< English >
Record Resolution	< 1920x1080 >
Record fps	< 60Hz >
Bitrate	< High >
File size	< 16G >
Loop Recording	< On >
Show REC	< On >
Time Watermark	< On >
System time	< 2021-03-11 10:41 >

  Change  Choose  Close



SYSTEM SETTING

Language: English, Simplified Chinese, Chinese, Japanese, Korean, German, French, etc.

Record Resolution: 1920x1080/1024X768/1280X720/1280X1024

Record fps: 50/60Hz

Bitrate: High/Med/Low

File Size: 16G/4G

Loop Recording: On/off





Show REC: On/off (Show logo REC)

Time watermark: On/off

System Time: 2021-XX-XX XX:XX



Image Setting

Image Setting    

Brightness	<	75	>
Contrast	<	75	>
Saturation	<	50	>
Backlight	<	90	>
Update	<		>
Restore	<		>
Version	<	20210215	>





  Change  Choose  Close



Image Setting

Brightness : 0-100

Contrast : 0-100

Saturation : 0-100

Backlight : 0-100

Update :

Restore :

Version : 20210215



Audio Setting

The screenshot shows an audio settings menu with a dark blue background. At the top, there are four icons: a speaker with a gear, a volume knob with a gear, a speaker with a gear, and a calendar with a gear. Below these icons, the text "Audio Setting" is displayed. The menu lists six audio settings, each with a left arrow, a value, and a right arrow:

Setting	Value
HDMI Volume	100
Mic Volume	55
Line Volume	10
Sperker Volume	100
Line out volume	100
Line out mixed	Off

At the bottom of the screen, there are three navigation options: "Change" (with a left arrow icon), "Choose" (with a right arrow icon), and "Close" (with a circular arrow icon).



Audio Setting

HDMI Volume: 0-100

Mic Volume: 0-60

Line Volume: 0-10

Sperker Volume: 0-100

Line OUt Volume: 0-100

Line Out Mixed: on/off



Schedule Setting



Schedule recorder : off/on

Schedule mode : Per day/once

Schedule Setting

